

FIREBLADE 96-99 HUGGER

Fitting kit contents:

1 x Bracket
4 x M6 x 16mm allen bolts
4 x black plastic washers

Fitting instructions

the hugger is easy to fit, the bracket and hugger should be installed and carefully positioned before the fasteners are fully tightened.

Remove the original chainguard.

Using the original bolt, fit the bracket between the brace and clip so that the bracket hangs down under the brace.

Position the hugger over the original chainguard brackets and the new bracket. Secure with the four bolts and washers supplied.

Position the hugger centrally over the tyre and tighten all fasteners.

Note:

*Please check all fasteners and alignment of the hugger periodically.
This hugger is not designed for use with an oversize tyre*

