



CBF1000FA 2010-present HUGGER

Fitting kit:

2 x M6 x 16mm Flange headed allen bolt
1 x M5 x 16mm Flange headed allen bolt

Fitting instructions:

- 1) Remove rider and pillion foot peg on chain guard side of bike, this gives you access to remove the chain guard.
- 2) Remove rear most brake hose clip bolt and remove the plastic brake hose clip from the hose.
- 3) Slide hugger into position and loosely fit the M5 X 16mm bolt to the brake hose clip mounting.
- 4) Use the two M6 x 16mm bolts to loosely fit the chain guard side of the hugger.
- 5) Tighten all the fixings checking alignment of the hugger as doing so.
- 6) Re-attach the pillion and rider foot pegs.
- 7) Check all fixings are tight and check all fixings periodically.