

22160 Yamaha MT-09 Fly Screen Fitting Instructions

Kit Includes:

1X	C22160	Fly Screen
1X	CFK22160	Bracket
3X	CBOL0162	M5 X 16mm Stainless Bolt
3X	CNUT0156	M5 Rubber Anchor Nut
3X	CWAS0100	M5 Washer
4X	CBOL0219	M6 X 20mm Stainless Hex Bolt
4X	CWAS0221	M6 Washer
4X	CCAP0001	Bolt Cap

- The Pyramid fly screen is simple to fit. Attach the fly screen to the bracket using the M5 fixings supplied (CNUT0156, CBOL0162 & CWAS0100). See Fig 1 and Fig 2 below for images.
- Remove the OEM bolts from the top of the headlight. Retain the flat washers from beneath these OEM bolts for use when fitting the fly screen.
- Now fit the fly screen using the remaining items supplied in the fitting kit (CBOL0219, CWAS0221, CCAP0001). A spanner/wrench will be required in order to access the top of the M6 x 20mm stainless steel hex bolts.

Check fixings periodically.

Fig 1



Fig 2



Fig 3



Any questions?
sales@pyramid-plastics.co.uk
 +44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
 feel free to leave us a review!