



**INSTALLATION AND OWNER'S MANUAL**

**Z2400 VStream Replacement Windscreen  
for R 1150 RT  
Quantum Coated Lexan® Polycarbonate**

**Attention**



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

**Note:**



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



**TOOLS REQUIRED:**  
Torx Wrench, T25



Right and left side of motorcycle is determined while sitting on the bike.

**PARTS LIST**

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	VStream Windshield, Quantum Coated Lexan® polycarbonate	1

**INSTALLATION**



**Retain all fasteners, as they will be reused.**

1. Remove the 4 screws holding the outside plates on stock windshield. **(Torx Wrench, T25)**
2. Remove the 2 screws holding the stock windscreen to the mounts. **(Torx Wrench, T25)**
3. Place the ZTechnik VStream Windscreen into position on the stock windscreen mounts. Reinstall the original bolts through the windscreen and into the mounts. **(Torx Wrench, T25)**
4. Tighten the bolts firmly. **(Torx Wrench, T25)**
5. Reinstall the stock outside plates onto your new VStream using stock screws. **(Torx Wrench, T25)**

**MAINTENANCE**

**Cleaning:** Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

**Paint, glue residue removal:** Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

View ZTechnik® R 1150 RT products at  
[www.ZTechnik.com](http://www.ZTechnik.com)

CARBON FIBER KITS • EXHAUST SYSTEMS • STORAGE POD  
TECHMOUNT STANDS