



Attention



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:
3mm Allen Wrench



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	VStream Windshield, Quantum Coated Lexan® polycarbonate	1

INSTALLATION



Retain all fasteners, as they will be reused.
To facilitate reassembly, note the orientation of Covers and Bracket as you remove them in steps 1 and 2.

1. *Carefully* remove the two covers on outside of stock windshield.
2. Remove the four screws that hold the bracket and stock windscreen in place. Store stock windscreen it will not be reused.
3. Place your VStream Windscreen into position and install to motorcycle using the original screws, brackets and covers.
5. Tighten the bolts firmly. Do not over tighten. **(3mm Allan Wrench)**

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

Paint, glue residue removal: Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

View ZTechnik® K1200 LT products at
www.ZTechnik.com

LIGHTING SYSTEMS • REAR RACKS • ARM RESTS
TECHMOUNT STANDS • BAEHR COMMUNICATION SYSTEMS •
BAEHR COMMUNICATION SYSTEMS