



**VStream™ Windscreen  
Installation and Owner's Manual  
N20303 for FZ1 06-**

**Quantum™ Coated Lexan®  
polycarbonate**

**Attention**




Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

**Note:**



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



**TOOLS REQUIRED:**  
Phillips Screwdriver



Right and left side of motorcycle is determined while sitting on the bike.

**PARTS LIST**

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	Windshield, Quantum Coated Lexan® polycarbonate	1

**INSTALLATION**



**Retain all fasteners, as they will be reused.**

1. Remove the 6 screws holding the stock windshield. **(Phillips Screwdriver)**
2. Place National Cycle Windscreen into position on motorcycle. Replace stock screws.
3. Tighten the screws firmly. **Do not over tighten (Phillips Screwdriver)**

**MAINTENANCE**

**Cleaning:** Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

**Paint, glue residue removal:** Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.