



Attention



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	Windshield, Quantum Coated polycarbonate	1



Right and left side of motorcycle is determined while sitting on the bike.

INSTALLATION



Retain all fasteners and front plates, as they will be reused.



TOOLS REQUIRED:
Phillips Screwdriver
5/16" Wrench

1. Remove the 4 screws holding the front plates. **(Phillips Screwdriver)**
2. Remove the 4 screws holding the stock windshield. **(5/16" Wrench)**
3. Place VStream Windshield into position on motorcycle. Install windshield using 4 stock screws. Tighten the screws firmly. **Do not over tighten (5/16" Wrench).**
4. Place front plates on outside of windshield and secure with stock screws. Tighten the screws firmly. **Do not over tighten (Phillips Screwdriver).**

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

Paint, glue residue removal: Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

