

INSTALLATION INSTRUCTIONS For Suzuki C109

N7207, Rear of Rear Fender Tip

Attention



Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.

PARTS LIST FOR N7207

Part	<u>Description</u>	<u>Qty.</u>
70-710087-000	Rear of Rear Fender	1
BAG #588 42-423050-000 49-490531-000 55-568216-000	Nut, Nylok Washer Screw. M5	2 2 2

PREPARATION:

Thank you for purchasing a National Cycle product.

- Position motorcycle securely on its stand or a work stand.
- 2. Clean the fender thoroughly.

INSTALLATION of REAR FENDER TIP

- 1. Cover the area of the fender where the Fender Tip will mount with a thin layer of masking tape. Make certain the tape is smooth.
- 2. Carefully, position the Rear Fender Tip on the fender, make sure the Tip is centered on the fender. Figure 1
- 3. Mark the hole locations with the marking pen. Figure 2
- 4. Remove the Fender Tip.
- **5.** To avoid the drill slipping on the fender, use the Center Punch to make an impression at the center of your mark. Drill holes through the fender at the marks. **Figure 3**

Due to close clearances between front fender and tire, place block of wood between the fender and the tire to avoid tire damage. Figure 3

- 6. Remove the masking tape.
- **7.** Position the Fender Tip, and squeeze fender toward tip. Insert the Screws from the outside. Install the Washers and Nuts to the inside. Tighten securely. **Figure 4**

MAINTENANCE

Clean and polish with a chrome cleaner/polish. Check tightness of the nuts regularly.



Finished Installation, C109

TOOLS REQUIRED:

No. 2 Phillips Screwdriver

Masking Tape
Marking Pen
Small Wood Block 1/2" Thick (not shown)
Center Punch
Power Drill with 7/32" Drill Bit
5/16" Wrench





Figure 1 (The photos used are stock installation photos)



Figure 2







