


PARTS LIST

QTY.	DESCRIPTION
1	Speedometer Cowl
1	Alcohol Wipe



None Required

PREPARATION

Place the motorcycle securely on its side stand.
Thoroughly clean the speedometer area before installing the Speedometer Cowl. **DO NOT** use polishes or silicones.

INSTALLATION

1. **Before you remove tape liner**, determine the best mounting position by placing the Speedometer Cowl around speedometer.
2. Use the Alcohol Wipe to clean the area where the Speedometer Cowl is to be installed.
3. Remove the red backing from the adhesive on the underside of the Speedometer Cowl.
4. **Lightly** position the Speedometer Cowl in place around speedometer.
5. When the Speedometer Cowl is satisfactorily positioned, firmly press the Cowl in place.
6. Let adhesive tape set-up 4-6 hours before using motorcycle.

MAINTENANCE

Clean and polish with a chrome cleaner / polish.