



## Push-Rivet Extenda Fenda Fitting Instructions

- Remove the front guard from the bike - noting the position of any brake hoses/ABS lines.
- Clean the inside face of the mudguard with hot soapy water - dry thoroughly.
- Trial fit the Extenda Fenda before removing the backing tape to familiarise yourself with how the Extenda Fenda fits onto the mudguard.
- Now remove the backing tape and install the Extenda Fenda onto the mudguard ensuring that the rebate in the Extenda Fenda is aligned with the edge of the mudguard. - *Please note that it is possible to pull the Extenda Fenda away from the mudguard and realign at this stage. The gasket tape is supplied to hold the Extenda Fenda in the correct position whilst fitting.*
- Use the edge of four pieces of masking tape to mark four positions 8mm from the guard edge (one at each end of the Extenda Fenda and two equally spaced between).
- *It is important to drill the four holes accurately in relation to the edge of the mudguard.*
- Choose one end of the Extenda Fenda and drill the first 4mm diameter hole through both the mudguard and the Extenda Fenda - centre the drill on the edge of the masking tape. Clean away any plastic swarf and then push through the push-rivet whilst pressing the Extenda Fenda and mudguard faces together. Ensure that the two faces are held firmly together and that the push-rivet has opened out on the reverse side.
- Repeat in the other three positions and then re-fit the mudguard .
- Whilst the guard is loosely mounted there will be a small amount of adjustment available with regard to the final position of the mudguard. Take advantage of this to achieve the best gap between the bottom edge of the Extenda Fenda and the tyre before finally tightening the mudguard mountings.

**Visit [youtube.com/pyramidplastix](https://www.youtube.com/pyramidplastix) for our video tutorial on fitting a Push-Rivet Extenda Fenda**

**Alternatively you can contact us:  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990**

