

XJR1300 BELLY PAN

Contents:

4 x brackets
4 x M6 x25mm c/sunk allen bolt
4 x M6 c/sunk s/s washer
4 x M6 steel washer
4 x M6 nyloc nut

fitting instructions:

Remove bolts from front engine steady brackets and slacken main bolt which passes through all three. Place the “B” shaped brackets (A2) between the engine steady brackets and frame and replace bolts. The “B” shaped brackets should be stamped to show which is left and right but if not the “B” should face forwards and will line up with the front of the engine steady brackets. Tighten all bolts.

Remove kickstand cut out switch and place “U” shaped bracket marked B1 behind it, then replace the switch.

Remove the bottom two bolts on right side crank case and fit “Y” shaped bracket marked B2 and replace bolts.

When all four brackets are in place make sure all bolts are tight, then fit belly pan in place using fasteners supplied, fit the front two fasteners first loosely and then fit the rear. When all four bolts are in place ,tighten.

Please note: belly pan will reduce ground clearance, it may be advisable to adjust suspension to compensate especially if heavy loads are carried.

