


**BMW R1200 RT Infill Panels**  
Fitting Instructions  
(Best fitted with panniers off)

For best results, please read these Fitting Instructions carefully before commencing.

1. Using a T25 Torx spanner, take two retaining studs out of dark coloured peninsular side panel directly above the front footrest on left side of bike and hold panel away from bike with wedge of some description, for ease of fitting. (Roll of insulating tape works well). (see pic 1).
2. Take Infill Panel with 'L' marking (on back of boxed hole section) and feed it up from under side frame with pointed wedge (fin) section to the top right and boxed hole section to top left. (see pic 1)
3. Feed the pointed (fin) section up and back, trapping it between the bottom of bodywork of bike and the hanging V-shaped black tube frame section behind the rear footrest. You will need to ease the bodywork away a bit and push the Infill panel up and back. (Some force will be needed). At same time ease the front section past protuberances on inside of frame arm. While pushing panel rearwards, (until it covers rearmost black stay of V section), pull front box section towards you so wing with hole in it is in front of body panel with screw fixing and that the holes line up. (see pic 2).
4. Take wedge out of peninsular side panel and replace studs. (see pic 3).
5. Using T25 Torx spanner repeat same procedure on right side of bike with Infill Panel marked 'R'.



pic 1



pic 2



pic 3