

**GSX 1400 HUGGER**  
**FITTING INSTRUCTIONS.**

**FITTING KIT:**

- 1 x strap bracket,
- 2 x m6 x 10 dome head allen bolts,
- 2 x m6 x 12 dome head allen bolts,
- 1 x 20mm piece of rubber edge trim.
- 4 x M6 plastic washer.

1. Remove brake hose clamp bolt on right hand side.
2. Place strap bracket around swing-arm front area approx 70mm from chain.
3. Attach top piece of strap bracket and bolt 2 pieces together loosely using 2xm6x12mm bolts.
4. Feed hugger through from back and place arm of hugger under the brake hose.
5. Replace the brake hose clamp over the hugger and finger tight the original bolt.
6. Bolt the hugger to the strap bracket using the 2x m6x10mm bolts
7. If necessary move strap bracket so it is in line with holes on hugger and when all holes are in correct position remove hugger and tighten strap bracket bolts.
8. The 1” strip of rubber attaches to the hugger above the chain guard. (see pic below)

**NOTE:**

***ALL PYRAMID HUGGERS ARE DEVELOPED USING FACTORY STANDARD BIKES FITTED WITH STANDARD SIZED TYRES. THE FITTING OF AFTERMARKET UP-SIZED TYRES MAY AFFECT THE FIT OF OUR PRODUCTS.***

