## <u>CBR600RR 03/04</u> <u>HUGGER</u>

## **CONTENTS:**

## 3 X M6 X 16MM DOME ALLEN BOLTS 3 X PLASTIC WASHER

## **FITTING INSTRUCTIONS:**

Simply unbolt the standard hugger, then replace with the pyramid hugger using the bolts and washers provided.

