ZRX 1200 HUGGER

Fitting kit contents:

- 3 x self tapping screwbolts
- 3 x plastic washers

Fitting instuctions:

- 1. Insert hugger in over rear wheel from the back to the front.
- 2. Align with holes and hold in position by inserting one of the bolts through the hugger and into the hole on the underside of the swing arm brace. Do not fully tighten.
- 3. Insert the remaining two bolts into the two rearmost holes on either side of the inside of the swing arm.
- 4. Tighten all bolts fully starting with the 2 side bolts.
- 5. If better positioning is required simply loosen the bolts enough to move the hugger and then tighten the bolts up again while hugger is in the required position.
- 6. Some flexing of the hugger may be required in order to get the second bolt in.



