

# ZZR1400 HUGGER



## Fitting kit:

1 x bracket  
4 x M6 x 12mm button allen bolt  
4 x M6 nylon washer  
1 x M6 x 20mm button allen bolt  
1 x M6 steel washer  
1 x M6 Nyloc nut

## Fitting instructions:

Remove the chain guard.

On the right side of the swing arm, remove the bolt from the front brake hose guide. Gently pull the brake hose guide away from the upright tab on the swing arm, place the bracket provided over the tab with the main part of the bracket to the inside. (See pic).



using the M6 x 20mm bolt supplied, refit the brake hose guide to the tab, fully tightening the bolt, which should pass through the single hole in the bracket. Secure the bracket to the tab with the Nyloc nut and steel washer supplied to the rear of the bracket. Fully tighten.

Feed the hugger carefully in from the rear of the wheel. Loosely attach the chain guard side to the original mounts using two of the M6 x 12mm bolts with plastic washer. Use the two remaining bolts and washers to attach the hugger to the captive nuts in the bracket.

Check hugger alignment over the wheel then fully tighten all fasteners.

**Please note: check hugger alignment and fasteners periodically.**