

Contents:

4 x M6 x 20mm flanged button head bolts

4 x 13mm Grommet & Spacer

You will need: Allen keys and a spanner set.

Fitting instructions:

Remove original chain guard.

Remove exhaust can and both brake hose mountings.

Fit grommets and spacers to the 4 holes in the hugger. Fit the grommets first to aid fitting.

Slide hugger over the tyre from the rear and attach the front fixing point on the exhaust can side with the brake hose clip on top of the rubber grommet and finger tighten. (This can be quite fiddly and may take several attempts).



Next fit the rear mounting point on the exhaust can side with the brake hose clip on top of the rubber grommet and finger tighten.



Now fit both mounting points on the chain guard side and tighten all mounting points fully. Finally re-fit the exhaust can.

Note:

Please check all fasteners and alignment of the hugger periodically.

When riding two up, offroad and on rough surfaces, please adjust the spring preload tension to compensate for the extra added weight as the battery box can collide with the Hugger due to the long shock travel's initial set up. Please consult your owners manual for adjustment.