



MT-09 Frame Infill Panels

Fitting kit

1 x 430x5mm cable tie

Fitting Instructions

- Remove seat.
- Remove the pillion foot pegs.
- Put the right hand panel in place and fix using the original bolts and the foot peg positioned over the mounting tab of the panel.
- Repeat for the left hand panel
- Feed cable tie through the slots in the top of each panel, ensuring it runs under the fuel tank bracket.
- Pull cable tie tight.
- Ensure all pillion foot peg bolts are fully tightened
- **Check all fixings periodically.**