## **FALCO HUGGER**

## **Fitting kit:**

- 3 x M5 x 16mm posi screws
- 3 x M5 washers
- 2 x Nylon washer
- 2 x cable ties (including one spare)

## **Fitting instructions:**

Before fitting the hugger it is necessary to remove or modify the original mud flap. The mounting bolts are accessed through the bottom of the battery box. Alternately cut 60mm from the bottom of the flap.

In the first instance mount the hugger without fully tightening the fasteners.

Remove the chain guard.

Unbolt the brake hose guide from inside the right spar of the swing arm.

For access, remove the left side pillion foot rest hanger.

Pass the cable tie through the inner hole in the underside of the right side hugger 'nose' and pass it back out through the hole in the 'point'.

Position the hugger, ensure the cable tie passes inside the swing arm and that the hugger tab fits between the hose guide mount and the swing arm.

Secure the hugger at the three fixing points using the screws supplied with steel washers and also nylon washers on the chain guard mounts, applying a drop of loctite or a similar thread retaining compound to each screw.

Check hugger alignment before finally tightening all fasteners.

Pass the cable tie between the swing arm and the hose guide and secure, cutting off excess.

Please note: check hugger alignment and fasteners periodically.