



BMW R1200 GS INFILL PANELS

Fitting Kit:
2 x Infill Panel
2 x Zip Tie / Cable Tie
2 x Adhesive Foam Strip



1. Remove the rear seats. If there is a tax disc attachment below the rear passenger seat, remove that also.



2. Starting with the left infill panel, peel off the protective layer from the adhesive foam pad and place the adhesive strip onto the frame mounting grip, foam facing outwards.



3. Slide the panel up and over the left pannier mounting bracket. Slide the frame mounting grip (with foam) up and clip into position.



4. Firmly push the Infill Panel Locking Clip under the Rear Seat leading edge. Press both parts together and slide the Infill Panel underneath.



5. Thread the cable tie through the hole in the Infill Panel. There is a hole in the chassis frame where other cable ties are present that is lined up with the hole in the Infill Panel. Thread the cable tie through the chassis and tie up tight. Cut off any excess as necessary.