

CBR1100XX BLACKBIRD SSC

CONTENTS:

2 x brackets marked 1 and 2
2 x M6 x 16mm c/sunk allen bolt
2 x M6 c/sunk stainless steel washer
2 x rubber washer
2 x ½” self tapping screw
2 x flat steel washer
4 x rubber edge trim

Fitting instructions:

When fitting this cowl the grab rail should be removed along with the four steel collar inserts.

The only modification required is to drill two 3mm holes in the plastic seat base to fix the front brackets “1” and “2”. To achieve the correct position when drilling these holes first cut out the two paper templates and carefully place them in the base of the seat as shown in the diagram. Then with a sharp instrument mark the centre for drilling the hole through the paper.

Locate the bracket marked 1 to the left side of the seat base as per the sketch. The bracket can now be fixed using the self tapping screw and flat washer provided. The bracket hole is intentionally oversize to allow some adjustment. Repeat for the bracket marked 2 on the right side of the seat. The two brackets now provide the main fixing for the cowl and be left in place for easy fitting and removal.

The cowl can now be fitted to the seat with the edge trim on the front edges in the area of the seat sides to prevent damage to the seat vinyl. The other two pieces can be attached to the rear corners of the cowl if necessary to prevent contact between the cowl edge and the paintwork on the seat tail unit.

The seat and seat cowl can now be fitted and removed as a unit.

