

CBR900 00/01 HUGGER

Fitting kit:

1 x M6 x 16mm button allen bolt
2 x M6 nylon washer
1 x M6 s/steel washer
1 x plastic rivet fixing

Fitting instructions:

Remove the original chain guard.

The nylon fitting will pull out once the inner screw has been undone a few turns.

Remove the brake hose clamp from the top of the swing arm spar.

In the first instance, do not fully tighten the fasteners

Position the hugger, re-fit the hose clamp using the original screws (apply loctite or similar thread retaining compound).

Secure the hugger to the chain guard mounts using the bolts supplied (apply loctite or a similar thread retaining compound) with nylon washer and the new plastic fitting.

VERY IMPORTANT – **Position the remaining nylon washer under the head of the new plastic fitting.**

Insert the fixing and “tap” the screw home with a light mallet.

Check hugger alignment before finally tightening all fasteners.

Please note: check hugger alignment and fasteners periodically.