

# VFR800 V-TEC HUGGER

## Fitting kit:

1 x Bracket  
2 x M6 x 12mm button allen bolt  
2 x M5 x 16mm allen bolts  
2 x Nylon washer  
2 x M6 s/steel washer  
2 x 420mm cable tie

## Fitting instructions:

### **N.B.**

At Pyramid we pride ourselves on the quality of our hugger fitting kits and usually avoid the use of cable ties. In this instance we felt the use of a cable tie, with the hugger moulding specifically designed to make mounting as secure and neat as possible, was preferable to using a large steel bracket.

Remove the two screws that retain the hose clips on top of the chain guard. Position the bracket on top of the clips and secure with the M5 bolts supplied, using loctite.

Pass the cable tie through each of the holes in the lower extension, up and back down through the holes in the “nose”. Leave approx 50mm of the cable tie protruding through the lower hole.

Position the hugger and secure to the bracket using the M6 bolts, **but do not fully tighten at this stage.**

Pass the end of the cable ties down through the swing arm either side of the spring and linkages. Ensure that the cable ties do not pass through the spring.

Join each cable tie to its original end, check the hugger alignment and tighten the cable ties. Cut off excess ends.

Finally recheck the hugger alignment, remove and refit the M6 bolts using the s/steel and nylon washers and loctite or a similar thread retaining compound to the threads.

**Please note: check hugger alignment and fasteners periodically.**