

# KTM Duke 125/200/390 Rear Hugger

## Kit Includes:-

2x M6 Grommets with sleeves

2x M6 x 20mm flange headed bolt

2x m6 plastic washer

1x M5 x 20mm flange headed bolt

1x M6 Nyloc nut



1. Remove the bolt on the bottom right of the gear pedal assembly and loosen (not remove) the ones on the bottom right and centre

2. Remove existing chain and rear guards

3. Insert the grommets and sleeves into the two 13mm holes on the right hand side of the hugger

4. Place the hugger onto the bike and insert the M5 x 20mm Flange headed bolt into the **REAR** most grommet and place one of the M6 x 20mm bolts into the **FRONT** most grommet

5. Replace the existing bolt back into the front mounting point for the chain guard also using one of the plastic washers

6. Place the remaining M6 x 20mm flange headed bolt and remaining plastic washer into the rear mounting point of the old chain guard using the M6 Nylock nut, Finally check the fit of the hugger, go round and tighten