

Kit Includes:-

2x M6 Grommets with sleeves

2x M6 x 20mm flange headed bolt

1x Nylon spacer



1. Remove the existing chain guard and hugger.
2. Fit the rubber grommets in the two 13m holes at the front of the hugger.
3. Insert the two steel sleeves into the rubber grommets.
4. Feed the hugger into position.
5. Use the M6 bolts provided to loosely fit the two grommet mountings (don't tighten)
6. Next fix the rear most chain guard mounting using the nylon spacer provided, with the existing bolt.. (don't tighten)
7. Now fit the forward most mounting of the chain guard using the existing bolt.
8. Check alignment and fully tighten all mountings.
9. Check all fixings periodically.