

# S1000XR Hugger 2015>

## Fitting Kit:

4 x M6x20mm flange headed bolts  
4 x rubber grommets and spacers

## Instructions:

1. Remove the existing mudguard
2. Place the four rubber grommets in the mounting holes of the hugger with the steel collars fitted inside the grommets.
3. Place the hugger over the tyre and bolt into place using the 4 M6 x 20mm bolts provided, **Only fit loosely** until all the bolts are in place, then fully tighten.

Check the alignment of the hugger and make sure to **Always check all fixings periodically**