

MT-07 Spray Guard 085201

Fitting instructions

Note: You are advised NEVER to attach additional items ANYWHERE on this guard – such as mounting plates, indicators, lights, licence plates, crash protectors, etc as this will invalidate the warranty.

This spray guard is simple to fit using two allen keys.

This picture shows the Spray Guard in the correct position. The Spray Guard will rotate on the wheel spindle bracket to alternative positions - Please **do not** do this as it will cause a serious rider safety issue. **Fit only in the position shown here.**

To assemble simply pass the two long allen bolts through the hollow wheel spindle and fully tighten using two allen keys of at least 125mm length - You are effectively locking the loose bolt into the assembly by running it into the end of the threads of the central spacer.

Check all positions for clearance before your first ride. Bear in mind that there will be some movement of the Spray Guard head whilst riding. Also check that clearance is maintained after your first ride. It is important that this Spray Guard remains rigidly mounted at all times. If it is allowed to loosen permanent damage will be caused to the moulded castellation on the reverse of the Spray Guard.



MT-07 Spray Guard 085201

Fitting instructions

Note: You are advised NEVER to attach additional items ANYWHERE on this guard – such as mounting plates, indicators, lights, licence plates, crash protectors, etc as this will invalidate the warranty.

This spray guard is simple to fit using two allen keys.

This picture shows the Spray Guard in the correct position. The Spray Guard will rotate on the wheel spindle bracket to alternative positions - Please **do not** do this as it will cause a serious rider safety issue. **Fit only in the position shown here.**

To assemble simply pass the two long allen bolts through the hollow wheel spindle and fully tighten using two allen keys of at least 125mm length - You are effectively locking the loose bolt into the assembly by running it into the end of the threads of the central spacer.

Check all positions for clearance before your first ride. Bear in mind that there will be some movement of the Spray Guard head whilst riding. Also check that clearance is maintained after your first ride. It is important that this Spray Guard remains rigidly mounted at all times. If it is allowed to loosen permanent damage will be caused to the moulded castellation on the reverse of the Spray Guard.

