

Contents

- 2 x M6x16mm Flange headed bolts
- 2 x M6 Plastic washers
- 2 x M6 Nyloc nuts
- 1 x M10 Nordlock washer
- 1 x Bracket with rubber button

DO NOT FIT WITH ACROPOVIC EXHAUST

PLEASE CONTACT US FOR BRACKET SPACER REQUIRED WITH THIS EXHAUST

Fitting Instructions

- The bracket mounts on the upper inside bevel box mounting stud. Remove this nut, LEAVE THE WASHER IN PLACE, and fit the M10 Nordlock washer over the stud. Position the bracket over the stud with the rubber button resting on the swing arm and refit the nut using loctite or similar thread retaining compound.
- Remove the two bolts fixing the caliper tension bar leaving the bar in place.
- Slide the hugger over the tyre with the bracket fitting on the inside of the hugger and the hugger fitting over the tension bar.
- Re-fit the tension bar bolts and finger tighten
- Fit the two M6x16mm bolts with the plastic washers to the bracket mountings with the two M6 Nyloc nuts (finger tighten)
- Check hugger alignment and fully tighten all fixings.
- **Check all fixings periodically.**

