

Fitting Kit:

2 X M6 x 16mm flange headed bolts
1 X M5 x 16mm flange headed bolt
1 X "P" Clip

Instructions:

1. Remove the chain guard.
2. Unbolt and remove the rearmost brake hose mounting clip.
3. Feed hugger over the tyre and into position with the right hand mounting tab under the brake hose.
4. Using the M6 x 16mm flange headed bolts provided, loosely fit the two chain guard mountings but do not tighten fully.
5. Fit the "P" clip around the brake hose to replace the brake hose mounting clip.
6. Using the M5 x 16mm flange headed bolt provided, loosely fit the tab to the brake hose mounting point. The bolt then goes through the "P" clip to hold the brake hose in place.
7. Check the alignment of the hugger before fully tightening all mounting points.
8. **Please ensure all fixings are checked periodically.**