



BT1100 BULLDOG HUGGER

Fitting kit:

- 1 x Bracket with rubber button
- 2 x M6 x 16mm button allen bolt
- 2 x M6 x 35mm socket cap bolt
- 4 x M6 nyloc nut
- 4 x M6 nylon washer
- 6 x M6 s/steel washer

Fitting instructions:

Please read the instructions before proceeding. **Do not tighten fasteners fully in the first instance.**

The bracket mounts on the upper inside bevel box mounting stud. Remove this nut, LEAVE THE WASHER IN PLACE, position the bracket over the stud with the rubber button resting on the swing arm and refit the nut using loctite or similar thread retaining compound.

Position the hugger. Secure to the bracket using M6 x 16mm bolts, with s/steel and nylon washers outside and nyloc nuts.

The hugger is secured to the brake torque arm using the longer bolts with s/steel and nylon washers and nyloc nuts with s/steel washers.

Align the hugger before fully tightening fasteners.

Please note: check hugger alignment and fasteners periodically.