



Africa Twin Hugger 2016>

part # 071968

Fitting Kit:

- 2 X M6 x 16MM flange headed bolts – CBOL0251
- 1 X M5 x 16MM flange headed bolt – CBOL0162
- 2 X M6 Plastic Washer – CWAS0221
- 1 X Cable Tie – CAB0200

Instructions:

1. Remove the chain guard.
2. Unbolt and remove the rear-most brake hose mounting clip pictured below.
3. Feed hugger over the tyre and into position with the right hand mounting tab under the brake hose's and loosely fit the M5 x 16MM flange headed bolt.
4. Attach cable tie round brake hoses taking care not to over tighten.
5. Using the M6 x 16MM flange headed bolts and plastic washers provided, loosely fit the two chain guard mountings.
6. Check the alignment of the hugger, then fully tightening all round.
7. BE SURE TO CHECK FIXINGS PERIODICALLY.

