



## 08124 Yamaha XT1200Z Super Ténéré Ductail Fitting Instructions

Kit Includes:

1X	C08124	Moulding
2X	CFIT0013	Black Plastic Push Rivets

- Two 4mm holes need to be drilled on both sides of the OEM guard & Pyramid Ductail - see diagram below.
- Clean the OEM guard for maximum adhesion. Remove the backing paper from the pre-fitted tape and fit onto the OEM guard.
- Be sure to line up the mounting points when fitting, use the 2X Black Plastic Push Rivets to attach the Pyramid Ductail at these two mounting points.

Got questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and  
feel free to leave us a review!



## 08124 Yamaha XT1200Z Super Ténéré Ductail Fitting Instructions

Kit Includes:

1X	C08124	Moulding
2X	CFIT0013	Black Plastic Push Rivets

- Two 4mm holes need to be drilled on both sides of the OEM guard & Pyramid Ductail - see diagram below.
- Clean the OEM guard for maximum adhesion. Remove the backing paper from the pre-fitted tape and fit onto the OEM guard.
- Be sure to line up the mounting points when fitting, use the 2X Black Plastic Push Rivets to attach the Pyramid Ductail at these two mounting points.

Got questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and  
feel free to leave us a review!

