

## 30100 Honda Africa Twin & X-ADV Handguard Extensions Fitting Instructions

Kit Includes:

1X	C30100	Mouldings (pair)
1X		Stick-Fit Kit + Rivets

Clamps are required for fitting this product.

It is advised that the OEM Handguards are removed from the bike before fitting.

- Offer up the two fitting faces to familiarise yourself with how the Pyramid Handguard Extensions fit.
- Clean the fitting faces using the alcohol wipe provided. Once dry, apply the Stick-Fit Pads using the diagram below as a guide. There is no need to use all of the Stick-Fit Pads we have provided.
- Once the Stick-Fit Pads are in place, remove the backing paper and carefully position the Pyramid Handguard Extensions on the OEM Handguards.
- Now clamp the two parts together and leave for **36 - 48 hours**. It is very important to clamp each part evenly across the fitting face. We recommend the use of **3 clamps for each side** (6 clamps in total).
- **Push-Rivets are also provided for those who would prefer to fit the parts together mechanically.** You should use a 4mm drill bit to drill holes in the two locations shown below (dotted circles mark our recommended mounting points). We always advise the use of masking tape when drilling these holes to ensure a clean cut.

Got questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

