



Important Fitting Procedure

Fit Handguard as per handguard fitting instructions.

Loosely assemble the clamp to the handlebar as per diagram. Attach the handguard with applicable parts to the handlebar end and also to the clamp connector (2).

The clamp bolts must be tightened in the following order:

Tighten bolt (6) through the handguard to the clamp connector (2) of the clamp assembly.

Tighten bolt (3) to solidly lock the clamp connector (2) between the clamp saddles (1).

Tighten bolt (4) to secure the clamp assembly firmly to the handlebar.

Note: The clamp is designed to allow the nut on bolt (3) to pull into the recessed hole. This eliminates the need for a wrench after the bolt starts to tighten.