


36000 Triumph Tiger 900 & Tiger 850 Sport Spray Cover Fitting Instructions

Kit Includes:

1X	C36000	Spray Cover
1X	CTAP0052	Adhesive Pads
2X	CFIT0013	Push Rivets
1X	CWIP001	Alcohol Wipe

- The Pyramid spray cover will arrive fitted with adhesive pads to be used in conjunction with the 2 push rivets supplied.
- Be sure to make use of the alcohol wipe provided to clean the fitting area on the bike before attaching the Pyramid spray cover.
- Remove the backing paper and fit the Pyramid spray cover as shown in the images below. Take care and correctly align before pressing down on the adhesive pads.
- Once attached, drill two evenly spaced 4mm holes through both the Pyramid spray cover and the OEM plastic moulding. Insert the push rivets supplied for the final fit.

Note: customers can also use a polyurethane mastic like 'Sikaflex' to achieve a good fit without any need for push rivets.



Pyramid spray cover in situ



Positions for adhesive pads
(shapes may vary)



Pyramid spray cover in situ

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!