

085220 Yamaha MT-10/R1(M) Spray Guard fitting instructions

Kit Includes:

Plastic Guard	C085220
Aluminium Bracket	CFK085220

- The spray guard is ready to install without the need for adjustment.
- Use a 32mm socket to remove the OEM spindle nut, washer & tension block. Fit the spray guard in place of the tension block using the OEM spindle nut & washer removed.
- Chain adjustment should allow 15-20mm of slack at the centre of the bottom chain run.
- The two screw adjusters left and right of the swingarm, should have equal lengths of exposed threads. **See red circle in picture below.**
- Finally torque the wheel nut to the correct value of **180Nm / 134 lb-ft.**



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!