

## DL650 2012>/SV650 2016> Belly Pan Fitting Instructions

*This is for later models supplied **without** the oil cooler (2012 on)*

### Parts List:

3 x mounting brackets

6 x M6 x 16 flange head socket screws

4 X Ny-lock nut and flat steel washer

4 x rubber grommets and steel collars for above

Three brackets are supplied. Mount as shown below.

2 x M6 x 16 flange head socket screws are provided to mount the forward bracket in the pre-drilled holes in the engine casing. The other mountings use existing engine bolts.

Now insert the rubber grommets and steel collars in the four pre-drilled belly pan holes.

Now mount the belly pan with the 4 x M6 x 16 flange head socket screws, Ny-locks and washers provided.

