

22170 Yamaha MT-10 Belly Pan Fitting Instructions

Kit Includes:

1X	C22170	Belly Pan
3X	CFK22170	Brackets (3 parts)
4X	CBOLM60008	M6 x 16mm Bolt
4X	CWASM60003	M6 Washer
4X	CPNUT0001 <small>Pre-fitted by Pyramid</small>	Aluminium Nut

Attach the brackets using the OEM bolts on the bike (see **Fig 1 & 2**).

Attach the Belly Pan to the brackets using the M6 x 16mm bolts and M6 washers supplied.

Check fixings periodically.

