



**SUPPLEMENTAL INSTALLATION INSTRUCTIONS TO KIT HA.
FOR INSTALLATION OF N2220 OR N2290 HEAVY DUTY SHIELD
TO KAWASAKI VN1500.**

PARTS LIST FOR BAG 189

Qty.	Part No.	Description
1	34-350401-000	Frame Brkt. Offset Right
1	34-350501-000	Frame Brkt. Offset Left
4	50-503000-000	Bolt, 5/16-24 x 1/2" Hex
4	42-431000-000	Nut, 5/16-24 Whizlok
4	49-490310-000	Washer, 5/16

INSTALLATION

This supplemental installation instruction is to be used with manual 10-110521-000 from Kit HA.

1. Fasten the offset bracket from Bag 182 to the fork "R" clamp using the button screw and washer from Bag 165.

2. Fasten offset bracket from Bag 189 to the outside of offset bracket from Bag 182 using the 1/2" hex bolts, washers and nuts from Bag 189.

3. Install windshield to front of offset bracket as indicated in diagram below.

Refer to manual 10-110521-000 for final adjustment. Check windshield to be sure all hardware is firmly tightened.

