

## DL1000 07 HUGGER

### FITTING KIT:

1 x Hugger,  
1 x Black Strap bracket,  
4 x M6 x 16mm bolts,  
4 x Plastic washers,  
1 x M6 x 12mm allen bolt,  
1 x Strap backing piece

1. Remove chain guard.
2. Feed hugger in over rear wheel and place chain guard area over chain guard mount lugs.
3. Insert one bolt in each of the chain guard mount points and turn until the threads catch but leave loose.
4. Feed the strap bracket underneath the brake cable and onto the swing arm.
5. Attach backing piece (straight piece) of strap bracket by using only the lower, hex head, bolt at this stage and tighten only enough to hold in position. The distance from the black bolt on the brake calliper to the first point of the strap bracket should be approximately 60 mm.
6. Pull hugger over the top of the bracket and while making sure the backing piece to the strap bracket is in position, insert the 2 Allen bolts with washers in place and attach loosely.
7. The hugger with bracket attached can now be moved backwards or forwards if it is not sitting central to the tyre at the pointed section to the top of the hugger.
8. When you are satisfied the hugger is sitting in the desired position tighten the lower strap bracket bolt and then the 2 top ones.
9. Tighten the chain guard bolts

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.