

TOOLS REQUIRED:

- Masking Tape
- Marking Pen
- Small Wood Block 1/2" Thick
- Power Drill with 7/32" Drill Bit
- 8mm Wrench
- No. 2 Phillips Screwdriver

PARTS LIST:

| Part No. | Description | Qty. |
|----------------|----------------|------|
| VTX | | |
| 70-710046F-000 | Front of Front | 1 |
| 70-710046R-000 | Rear of Front | 1 |

ROCKET

| | | |
|---------------|----------------|---|
| 70-710071-000 | Front of Front | 1 |
| 70-710072-000 | Rear of Front | 1 |

Bag No. 448 BOTH VTX AND ROCKET

| | | |
|---------------|------------------|---|
| 42-423050-000 | Nut, M5 | 4 |
| 55-568216-000 | Screw, M5-8 x 16 | 4 |
| 49-490531-000 | Washer, Flat | 4 |

PREPARATION:

1. Position motorcycle securely on its stand or a work stand.
2. Clean the fender thoroughly.

INSTALLATION

1. Cover the area of the fender where the Fender Tip goes with a thin layer of masking tape. Make certain the tape is smooth. **Figure 1.**
2. Carefully, position the front Fender Tip on the fender, make sure the Tip is centered on the fender. **Figure 2.**
3. Mark the hole locations with the marking pen. **Figure 3.**
4. Remove the Fender Tip.
5. Drill holes through the fender at the marks. **Due to close clearances between front fender and tire, place block of wood between the fender and the tire to avoid tire damage. Figure 4.**
6. Remove the masking tape.
7. Position the Fender Tip and insert the screws from the outside.
8. Install the washers and nuts on the screws and tighten securely. **Figure 5.**
9. Repeat the above steps to install the Tip to the rear of the front fender.

MAINTENANCE

Clean and polish with a chrome cleaner/polish. Check tightness of the nuts regularly.



Figure 1.



Figure 2.



Figure 3.



Note: Hold the drill so the drill bit goes into the fender straight.

Figure 4.




Figure 5.



Finished Installation VTX



Finished Installation Rocket

INSTALLATION INSTRUCTION FOR CAST FENDER TIP
Honda VTX 1300R, N7006 Rear Fender Tip
and for Triumph Rocket, N7071 Rear Fender Tip

TOOLS REQUIRED:

- Masking Tape
- Marking Pen
- Power Drill with 7/32" Drill Bit
- 8mm Wrench
- No. 2 Phillips Screwdriver

PARTS LIST:

| Part No. | Description | Qty. |
|--------------------|------------------|------|
| VTX | | |
| 70-710047-000 | Rear of Rear | 1 |
| Bag No. 447 | | |
| 42-423050-000 | Nut, M5 | 2 |
| 55-568212-000 | Screw, M5-8 x 12 | 2 |

ROCKET

| | | |
|--------------------|------------------|---|
| 70-710073-000 | Rear of Rear | 1 |
| Bag No. 588 | | |
| 42-423050-000 | Nut, M5 | 2 |
| 55-568216-000 | Screw, M5-8 x 16 | 2 |
| 49-490531-000 | Washer | 2 |

PREPARATION:

1. Position motorcycle securely on its stand or a work stand.
2. Clean the fender thoroughly.

INSTALLATION

1. Cover the area of the fender where the Fender Tip goes with a thin layer of masking tape. Make certain the tape is smooth. **Figure 1.**
2. Carefully, position the Rear Fender Tip on the fender, make sure the Tip is centered on the fender. **Figure 1.**
3. Mark the hole locations with the marking pen. **Figure 1.**
4. Remove the Fender Tip.
5. Drill holes through the fender at the marks. **Figure 2.**
6. Remove the masking tape.
7. Position the Fender Tip and insert the screws from the outside.

Note: In installation of Triumph Rocket Rear Tip add a washer to the screw before securing with nut on inside.

8. Install the nuts on the screws and tighten securely. **Figure 3.**

MAINTENANCE

Clean and polish with a chrome cleaner/polish. Check tightness of the nuts regularly.



Figure 1. Tape Fender, Position Fender Tip, Mark Fender



Figure 2.




Figure 3. Note: Rocket Installation, Add Washer to Screw Before Securing Nut



Finished Installation Rocket



Finished Installation VTX